

## Downdraft Spraybooth Airflow Data







All measurements should be made with a non-averaging velometer. Measure at door handle height, completely around vehicle.

For additional information, contact: